SIMALFA

WATER BORNE ADHESIVES



Installation Instructions

Free Flowing System: 5-Gallon - 20kg

US Patents: 5,868,319 & 6,042,024



1. Attach the spray gun to stainless steel fitting on Free Flowing hose.



2. Attach Free Flowing hose to SIMALFA container and make sure it is tightened securely.



3. Locate and prepare a location to install the completed Free Flowing system. Turn the container over so the hose connection is facing down, properly place in position and attach compressed air to begin spraying.

Box Height Off Floor: 10 feet

Atomization Air Pressure: 25-40psi maximum Spray Gun: SIMALFA HVLP with built in regulator

Fluid Hose Length: 12'

SPECIAL NOTICE:

Be certain not to apply stress onto the area where the hose attaches to the box. Undo stress can cause the compression fitting to release from liner.

Fax: 973.423.9264

Always follow proper safety procedures.

