

SIMALFA[®]**WATER BORNE ADHESIVES**

Installation Instructions

Free Flowing System: 110-Gallon - 440kg

US Patents: 5,868,319 & 6,042,024



1. Inspect the tote for any damage that may have occurred during shipping. Place tote on rack in the desired location.



2. Remove valve safety cap and connect the male camlock adaptor.

WARNING: Do Not touch internal valve components as opening of the valve may occur!



3. Connect the female camlock that's currently attached to the 2" PVC hose to the male camlock adaptor already on the tote and lock in place with the locking arms of the Camlock.



4. Secure the 2" hose down along the edge of the rack with the supplied cable ties. Provide adequate slack near the Camlock to relieve any stress on the tote valve and to aid in the ease of replacing the tote when empty.

2 Installation Instructions: continued



5. Secure the valve assembly with the supplied cable ties.



6. Attach one end of the ½" fluid hose(s) to the ½" hose barb on the valve assembly(s) and the other end to the spray gun(s) using the small hose clamps. Make sure that all hose clamps are fastened securely. The hose(s) must be kept to a minimum length, maximum length is about 15'. Attach the air lines to the spray guns(s). System is now completely installed.



7. Attach the Valve Lever in position so the valve can be opened. The Valve Lever can be found secured to tote with cable tie.



8. Open valve.



9. Begin spraying.
For information on how to properly setup and maintain spray gun see SIMALFA Spray Gun Guide.